
## Zivid Stationary Mount

User Guide

(ZVDA-MNT-ST10)



## **Getting Started**

## Tools

Hex 4 and 6 mm

Torx 20, 25 and 30















Tilt-Roll

Pan-Tilt

The mount can be re-configured to be either in pan-tilt or tilt-roll. Before you install the mount, evaluate which configuration that best suits your application.

To re-configure the mount, loosen the four M4 screws at the host and adapter plate, and re-attach them

in the new configuration with torque 1,5 Nm.

